CHICOLORES TECHNICAL RIDER

PA-ANFORDERUNG

 Wir bevorzugen ein amtliches PA-System (d&b, Nexo, Meyersound); das System sollte entsprechend dem Veranstaltungsort dimensioniert und eingemessen sein und zusätzlich einen gewissen Headroom haben (110dBa SPL am FOH)

FOH

40-Kanal-FOH-Pult (Midas, Allen&Heath, Soundcraft Vi1, Yamaha LS9-32, Behringer X32), idealerweise mit 16
 Aux-Sends (10 pre, 6 post), für Monitorbedienung vom FOH-Platz

Bei analogen Pulten benötigen wir zusätzlich:

- 22 Kompressoren (BSS, dbx, kein Behringer!!)
- 10 Gates (BSS, dbx, kein Behringer!!)
- 1 amtlicher Hall-Prozessor (PCM90/PCM91, M3000)
- 3 Multi-FX-Prozessoren (SPX90/SPX990)
- 1 Tap-Delay (D-Two, o.ä.)
- 31-Band-EQs für PA und Monitorwege (BSS, Klark)

BÜHNE / MONITORE

- Drumsriser 2x2 m, 60 cm hoch, mit Molton-Abhängung (schwarz)
- Podest für Bläser 2x1 m, 40 cm hoch, mit Molton-Abhängung (schwarz)
- *Podest für Percussion 2x2 m, 40 cm hoch, mit Molton-Abhängung (schwarz)
- schwarzer Backdrop
- 5 Monitor-Wedges (d&b Max/M4. o.ä.), der Drummer nutzt in-Ear (bitte einen Monobus am Drumriser bereitstellen), Saxophon und Trompete benutzen in-ear (Funkstrecke wird selbst mitgebracht, zusätzlicher Monobus für Monitoring notwendig), *bei Besetzung inkl. Percussion wird 1 zusätzlicher Monitor-Wegde benötigt.

LICHT

- Vernünftig eingeleuchtete Bühne, nach Möglichkeit Stufenlinsen als Frontlicht
- Gerne viel "intelligentes Licht" (nach Absprache)


SONSTIGES

- Wir benötigen einen fähigen Lichttechniker, sowie einen mit dem Beschallungssystem vertrauten Tontechniker
- Der FOH-Techniker kommt in der Regel von uns

CHICOLORES TECHNICAL RIDER

СН			FOH
1	Kick Drum	Grenzfläche	Comp Gate
2	Snare oben	Shure SM57	Comp
3	Snare unten	Shure SM57	Comp
4	HiHat	AKG C391, o.ä.	Deesser
5	Racktom 1	Shure Beta 98, Beta 56	Comp Gate
6	Racktom 2	Shure Beta 98, Beta 56	Comp Gate
7	Floortom	Shure Beta 98, Beta 56	Comp Gate
8	Overhead left	AKG C391, o.ä.	Comp
9	Overhead right	AKG C391, o.ä.	Comp
10	Bass	DI aktiv	Comp
11	Bass Mic	PL20	Comp Gate
12	E-Git	Sennheisser 906	Comp Gate
13	iPod für Pausenmusik	DI aktik	
14	iPod für Pausenmusik	DI aktik	
15	Keyboard left	DI aktiv	
16	Keyboard right	DI aktiv	
17	Voc Keyboard	Shure Beta 58	Comp
18	Voc Male	Shure Beta 87 UHF wireless	Comp Deesser
4.0	Voc Female	Shure Beta 87 UHF wireless	Comp
19	VOC I Elliale	Siture Beta 67 Offi Wileless	Comp
	Voc Git	Shure Beta 58	Comp
	Voc Git		
20	Voc Git	Shure Beta 58	Comp
20	Voc Git Sax	Shure Beta 58 Sennheiser MD421, Shure SM57	Comp
20 21 22	Voc Git Sax Trumpet	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57	Comp Comp
20 21 22 23	Voc Git Sax Trumpet Percussion*	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv	Comp Comp Comp
20 21 22 23 24	Voc Git Sax Trumpet Percussion* Percussion*	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv	Comp Comp Comp Comp
20 21 22 23 24 25	Voc Git Sax Trumpet Percussion* Percussion*	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56	Comp Comp Comp Comp Comp Comp
20 21 22 23 24 25 26	Voc Git Sax Trumpet Percussion* Percussion* Percussion*	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion*	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27 28 29	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion* Percussion*	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 AKG C391, o.ä.	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27 28 29	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion* Percussion* Percussion* OH L Percussion* OH R	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 AKG C391, o.ä. AKG C391, o.ä.	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27 28 29 30 31	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion* Percussion* Percussion OH L Percussion* OH R FX Return	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 AKG C391, o.ä. AKG C391, o.ä.	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27 28 29 30 31	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion* Percussion* Percussion OH L Percussion* OH R FX Return	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 AKG C391, o.ä. AKG C391, o.ä. Voc Hall L	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27 28 29 30 31	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion* Percussion* Percussion OH L Percussion OH R FX Return FX Return	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 AKG C391, o.ä. AKG C391, o.ä. Voc Hall L Voc Hall R Drum Room L	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27 28 29 30 31 32 33	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion* Percussion* Percussion OH L Percussion OH R FX Return FX Return FX Return FX Return	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 AKG C391, o.ä. AKG C391, o.ä. Voc Hall L Voc Hall R Drum Room L Drum Room R	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate
20 21 22 23 24 25 26 27 28 29 30 31 32 33	Voc Git Sax Trumpet Percussion* Percussion* Percussion* Percussion* Percussion* Percussion* OH L Percussion* OH R FX Return FX Return FX Return FX Return FX Return	Shure Beta 58 Sennheiser MD421, Shure SM57 Sennheiser MD421, Shure SM57 DI aktiv DI aktiv Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 Shure Beta 98, Beta 56 AKG C391, o.ä. AKG C391, o.ä. Voc Hall L Voc Hall R Drum Room L Drum Room R Special FX L	Comp Comp Comp Comp Comp Comp Comp Gate Comp Gate

CHICOLORES Stageplan



Steckdose Bühnenstrom